

---

# **ARES-5320 Series**

**Fanless DIN-Rail Embedded System with  
Intel® Elkhart Lake Atom Processor**

## **User's Manual**

**Version 1.0**

---

## Revision History

Version	Date	Description
1.0	2024.04	Initial release

<b>Revision History .....</b>	<b>ii</b>
<b>Contents .....</b>	<b>i</b>
<b>Preface.....</b>	<b>iii</b>
Copyright Notice .....	iii
Declaration of Conformity .....	iii
CE.....	iii
FCC Class A .....	iii
RoHS .....	iv
SVHC / REACH .....	iv
Important Safety Instructions .....	v
Warning.....	vi
Technical Support .....	vi
Warranty.....	vii
<b>Chapter 1 - Introduction.....</b>	<b>1</b>
1.1. About this Manual .....	2
1.2. Specifications.....	2
1.3. Inside the Package .....	5
1.4. Ordering Information.....	6
<b>Chapter 2 - Getting Started.....</b>	<b>7</b>
2.1. Dimensions .....	8
2.2. Overview .....	10
2.2.1. Back View .....	11
2.2.2. Top & Bottom View .....	12
2.3. LED Indicator Status .....	15
2.4. Driver Installation Note.....	16
<b>Chapter 3 - Engine of the Computer.....</b>	<b>17</b>
3.1. Board Overview .....	18
3.1.1. Jumpers & Connectors .....	19
3.1.2. Jumpers & Connectors Settings .....	20
3.2. Daughter Board - SCDB-148Q .....	26
3.2.1. Connectors Settings .....	27
<b>Chapter 4 - Installation and Maintenance.....</b>	<b>29</b>
4.1. Disassembling and Assembling the Computer .....	30
4.1.1. Disassembling the Computer.....	30
4.1.2. Assembling the Computer.....	31
4.2. Installing the Hardware .....	31
4.2.1. Installing a Memory Module.....	31
4.2.2. Installing a SSD/HDD (for -x6425A and -x6425P) .....	33
4.2.3. Installing a SIM Card and relative connection module.....	34

# Contents

---

4.2.4. Installing Wi-Fi Module .....	35
4.2.5. Installing GPS Module .....	38
4.3. Ground the Computer .....	42
4.4. Wire DC-in Power Source .....	43
4.4.1. Automation Mode .....	43
4.4.2. Vehicle Application Mode .....	44
4.5. Mounting .....	45
4.5.1. Wall Mounting .....	45
4.5.2. DIN-Rail Mounting .....	46
<b>Chapter 5 - BIOS .....</b>	<b>49</b>
5.1. Main .....	52
5.2. Advanced .....	53
5.2.1. CPU Configuration .....	54
5.2.2. PCH-FW Configuration .....	55
5.2.3. Trusted Computing .....	56
5.2.4. ACPI Settings .....	58
5.2.5. Super IO Configuration .....	59
5.2.6. Hardware Monitor .....	61
5.2.7. S5 RTC Wake Settings .....	62
5.2.8. Serial Port Console Redirection .....	63
5.2.9. USB Configuration .....	64
5.2.10. Network Stack Configuration .....	66
5.2.11. NVME Configuration .....	67
5.2.12. SDIO Configuration .....	68
5.3. Chipset .....	69
5.3.1. System Agent (SA) Configuration .....	70
5.3.2. PCH-IO Configuration .....	73
5.4. Security .....	77
5.4.1. Security Boot .....	78
5.5. Boot .....	79
5.6. Save & Exit .....	80
<b>Appendix .....</b>	<b>81</b>
Appendix A. DIO Signal Connections .....	82
A.1. 8-Bit DIO Signal Connections (for -x6425A and -x6425P) ....	82
A.2. 16-Bit Opto-Isolated DIO Signal Connections (for -ISO) ....	83
A.2.1. Wet Contact DI with NPN / PNP connection .....	83
A.2.2. Dry Contact DI with NPN / PNP connection .....	84
A.2.3. Isolated Digital Output Connections .....	85



## Copyright Notice

All Rights Reserved.

The information in this document is subject to change without prior notice in order to improve the reliability, design and function. It does not represent a commitment on the part of the manufacturer.

Under no circumstances will the manufacturer be liable for any direct, indirect, special, incidental, or consequential damages arising from the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this document may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

## Declaration of Conformity

### CE

The CE symbol on your product indicates that it is in compliance with the directives of the Union European (EU). A Certificate of Compliance is available by contacting Technical Support.

This product has passed the CE test for environmental specifications when shielded cables are used for external wiring. We recommend the use of shielded cables. This kind of cable is available from ARBOR. Please contact your local supplier for ordering information.

### Warning

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

### FCC Class A

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

### NOTE:

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### RoHS

ARBOR Technology Corp. certifies that all components in its products are in compliance and conform to the European Union's Restriction of Use of Hazardous Substances in Electrical and Electronic Equipment (RoHS) Directive 2002/95/EC.

The above mentioned directive was published on 2/13/2003. The main purpose of the directive is to prohibit the use of lead, mercury, cadmium, hexavalent chromium, polybrominated biphenyls (PBB), and polybrominated diphenyl ethers (PBDE) in electrical and electronic products. Member states of the EU are to enforce by 7/1/2006.

ARBOR Technology Corp. hereby states that the listed products do not contain unintentional additions of lead, mercury, hex chrome, PBB or PBDB that exceed a maximum concentration value of 0.1% by weight or for cadmium exceed 0.01% by weight, per homogenous material. Homogenous material is defined as a substance or mixture of substances with uniform composition (such as solders, resins, plating, etc.). Lead-free solder is used for all terminations (Sn(96-96.5%), Ag(3.0-3.5%) and Cu(0.5%)).

### SVHC / REACH

To minimize the environmental impact and take more responsibility to the earth we live, Arbor hereby confirms all products comply with the restriction of SVHC (Substances of Very High Concern) in (EC) 1907/2006 (REACH --Registration, Evaluation, Authorization, and Restriction of Chemicals) regulated by the European Union.

All substances listed in SVHC < 0.1 % by weight (1000 ppm)

## Important Safety Instructions

Read these safety instructions carefully

1. Read all cautions and warnings on the equipment.
2. Place this equipment on a reliable surface when installing. Dropping it or letting it fall may cause damage
3. Make sure the correct voltage is connected to the equipment.
4. For pluggable equipment, the socket outlet should be near the equipment and should be easily accessible.
5. Keep this equipment away from humidity.
6. The openings on the enclosure are for air convection and protect the equipment from overheating. **DO NOT COVER THE OPENINGS.**
7. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
8. Never pour any liquid into opening. This may cause fire or electrical shock.
9. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
10. If one of the following situations arises, get the equipment checked by service personnel:
  - a. The power cord or plug is damaged.
  - b. Liquid has penetrated into the equipment.
  - c. The equipment has been exposed to moisture.
  - d. The equipment does not work well, or you cannot get it to work according to the user's manual.
  - e. The equipment has been dropped or damaged.
  - f. The equipment has obvious signs of breakage.
11. Keep this User's Manual for later reference.

## **Warning**

The Box PC and its components contain very delicately Integrated Circuits (IC). To protect the Box PC and its components against damage caused by static electricity, you should always follow the precautions below when handling it:

1. Disconnect your Box PC from the power source when you want to work on the inside.
2. Use a grounded wrist strap when handling computer components.
3. Place components on a grounded antistatic pad or on the bag that came with the Box PC, whenever components are separated from the system.

## **Technical Support**

If you have any technical difficulties, please consult the user's manual first at:  
<http://www.arbor.com.tw>

Please do not hesitate to call or e-mail our customer service when you still cannot find out the answer.

<https://www.arbor-technology.com>

E-mail:[info@arbor.com.tw](mailto:info@arbor.com.tw)

## **Warranty**

This product is warranted to be in good working order for a period of one year from the date of purchase. Should this product fail to be in good working order at any time during this period, we will, at our option, replace or repair it at no additional charge except as set forth in the following terms. This warranty does not apply to products damaged by misuse, modifications, accident or disaster.

Vendor assumes no liability for any damages, lost profits, lost savings or any other incidental or consequential damage resulting from the use, misuse of, or inability to use this product. Vendor will not be liable for any claim made by any other related party.

Vendors disclaim all other warranties, either expressed or implied, including but not limited to implied warranties of merchantability and fitness for a particular purpose, with respect to the hardware, the accompanying product's manual(s) and written materials, and any accompanying hardware. This limited warranty gives you specific legal rights.

Return authorization must be obtained from the vendor before returned merchandise will be accepted. Authorization can be obtained by calling or faxing the vendor and requesting a Return Merchandise Authorization (RMA) number. Returned goods should always be accompanied by a clear problem description.

---

This page is intentionally left blank.

---

# Chapter 1

## Introduction

## 1.1. About this Manual

This manual covers several SKUs of the ARES-5320. Product features, installation images and BIOS screens may vary from model to model.

The table below lists the ARES-5320 SKUs and the major variants:

	CPU	DI/DO	LAN	COM	Storage
<b>ARES-5320-x6425A</b>	Soldered onboard	8 x DI/O	3 x 2.5GbE	2 x RS232	1 x Onboard 64G eMMC 1 x Full-size mSATA slot (colay w/ mPCIe) 1 x 2.5" SSD/HDD tray
<b>ARES-5320-x6425P</b>			2 x 2.5G PoE + 1 x 2.5GbE	2 x RS232(Default)/422/485	
<b>ARES-5320-x6425A-ISO (BTO)</b>	Intel® Atom™ x6425RE Processor	8 x DI & 8 x DO w/ 2kV isolation	3 x 2.5GbE	2 x RS232 2 x RS232(Default)/422/485	1 x Onboard 64G eMMC 1 x Full-size mSATA slot (colay w/ mPCIe)
<b>ARES-5320-x6425P-ISO (BTO)</b>			2 x 2.5G PoE + 1 x 2.5GbE	4 x 2kV isolated RS232/422/485	

## 1.2. Specifications

System	
<b>CPU</b>	Soldered onboard Intel® Atom™ x6425RE Processor
<b>Memory</b>	1 x 260-pin DDR4 SO-DIMM sockets, supporting 3200MHz SDRAM up to 32GB
<b>Chipset</b>	SoC
<b>Graphics</b>	Intel® UHD Graphic for 10 <sup>th</sup> Gen Intel® Processors
<b>LAN Chipset</b>	3 x Intel® i226LM
<b>Watchdog Timer</b>	1~255 levels reset
<b>TPM</b>	dTPM 2.0
I/O	
<b>Serial Port</b>	2 x RS232 2 x RS232(Default)/422/485 4 x 2kV isolated RS232/422/485 (For -ISO ver.)



<b>USB Port</b>	3 x USB-A 3.2 Gen1 (5Gbps)
	1 x USB-A 2.0
<b>LAN</b>	3 x 2.5GbE (For A & A-ISO ver.)
	1 x 2.5GbE + 2 x 2.5GbE PoE (IEEE802.3af) (For P & P-ISO ver.)
<b>Video Port</b>	1 x DP++, up to 4096 x 2160@60Hz
	1 x VGA, up to 1920 x 1200@60Hz
<b>Audio Port</b>	1 x Mic-in
	1 x Line-out
<b>Digital I/O</b>	8 x DI/O (For A & P ver.)
	8 x DI & 8 x DO both w/ 2kV isolation (For -ISO ver.)
<b>Expansion Bus</b>	1 x Full-size mPCIe slot (USB2.0, colay w/ mSATA) w/ 1 x nano SIM slot
	1 x Full-size mPCIe slot (PCIe x1 + USB2.0)
	1 x Half-size mPCIe slot (PCIe x1 + USB2.0)
<b>Storage</b>	
<b>Type</b>	1 x Onboard 64G eMMC
	1 x Full-size mSATA slot (colay w/ mPCIe)
	1 x 2.5" SSD/HDD tray (For A & P ver.)
<b>Power Requirement</b>	
<b>Power Input</b>	DC 9~36V (4 pin terminal block: V+, V-, SW+, SW-)
<b>Power Ignition</b>	1 x 2 pin terminal block (IGN+, IGN-)
<b>Power Consumption</b>	Max. 65W
<b>Environmental</b>	
<b>Operating Temp.</b>	-20 ~ 70°C, ambient w/ air flow
<b>Storage Temp.</b>	-40 ~ 80°C
<b>Operating Humidity</b>	10-95% @ 70°C (non-condensing)
<b>Vibration</b>	5~500Hz 3 Grms X,Y,Z axis w/ eMMC, according to IEC 68-2-64

## Introduction

---

<b>Shock</b>	10G peak accel (11 m sec. duration), operation
	30G peak accel (11 m sec. duration), nonoperation
	According to IEC 68-2-27
<b>Qualification</b>	
<b>Certification</b>	CE, FCC (Class A), E-Mark
<b>Mechanical</b>	
<b>Construction</b>	Metal + Aluminum Alloy
<b>Mounting</b>	DIN-rail (standard)
	Wall mount (optional w/ CTOS BKT, but not supported for -ISO ver.)
<b>Weight</b>	1.9Kg
<b>Dimensions (W x D x H)</b>	70 x 125 x 190 mm
<b>OS Support</b>	
Windows 10 IoT / Windows 11 IoT / Ubuntu	

### 1.3. Inside the Package

Upon opening the package, carefully inspect the contents. If any of the items is missing or appears damaged, contact your local dealer or distributor. The package should contain the following items:



1 x ARES-5320 (Product outlook varies according to your model)

ARES-5320-x6425A/  
ARES-5320-x6425P

- User's manual
- 1 x DIN rail mount bracket
- 1 x 2.5" drive bracket & 1 x 2.5" SATA cable
- 4 x M3\*6mm screws (for DIN rail mount bracket)
- 8 x M3\*4mm screws (for 2.5" drive & bracket)
- 2 x M3\*6mm screws (for 2.5" SATA cable)
- 1 x 2-pin terminal block plug (for power ignition)
- 1 x 4-pin terminal block plug (for power input)
- 1 x 10-pin terminal block plug (for digital I/O)

ARES-5320-x6425A-ISO /  
ARES-5320-x6425P-ISO

- User's manual
- 1 x DIN rail mount bracket
- 4 x M3\*6mm screws (for DIN rail mount bracket)
- 1 x 2-pin terminal block plug (for power ignition)
- 1 x 4-pin terminal block plug (for power input)
- 2 x 10-pin terminal block plug (for digital I/O)

## 1.4. Ordering Information

<b>ARES-5320-x6425A</b>	ARES-5320 w/ 3 x 2.5GbE, 4 x COM, 4 x USB, 1 x DP, 1 x VGA, 8 x DI/O, 64G eMMC & <b>1 x 2.5" SSD/HDD Tray</b>
<b>ARES-5320-x6425P</b>	ARES-5320 w/ <b>2 x 2.5G PoE + 1 x 2.5GbE</b> , 4 x COM, 4 x USB, 1 x DP, 1 x VGA, 8 x DI/O, 64G eMMC & <b>1 x 2.5" SSD/HDD Tray</b>
<b>ARES-5320-x6425A-ISO (BTO)</b>	ARES-5320 w/ 3 x 2.5GbE, 8 x <b>COM(4 x isolated)</b> , 4 x USB, 1 x DP, 1 x VGA, <b>8 x isolated DI, 8 x isolated DO</b> & 64G eMMC
<b>ARES-5320-x6425P-ISO (BTO)</b>	ARES-5320 w/ <b>2 x 2.5G PoE + 1 x 2.5GbE</b> , 8 x <b>COM(4 x isolated)</b> , 4 x USB, 1 x DP, 1 x VGA, <b>8 x isolated DI, 8 x isolated DO</b> & 64G eMMC


---

# Chapter 2


## Getting Started

## 2.1. Dimensions


TOP VIEW  
(X6425A-ISO & X6425P-ISO)




TOP VIEW  
(X6425A & X6425P)




BOTTOM VIEW  
(X6425A-ISO & X6425P-ISO)




BOTTOM VIEW  
(X6425A & X6425P)





FRONT VIEW  
(X6425A)




RIGHT VIEW  
(X6425A-ISO & X6425P-ISO)  
(DIN RAIL MOUNT)




BACK VIEW  
(X6425A-ISO & X6425P-ISO)




FRONT VIEW  
(X6425P)



RIGHT VIEW  
(X6425A & X6425P)




BACK VIEW  
(X6425A & X6425P)  
(WALL MOUNT)



BACK VIEW  
(X6425A & X6425P)  
(DIN RAIL MOUNT)

## 2.2. Overview






### 2.2.1. Back View

**ARES-5320-x6425A-ISO &  
ARES-5320-x6425P-ISO**


**ARES-5320-x6425A &  
ARES-5320-x6425P**



### 2.2.2. Top & Bottom View ARES-5320-x6425A & ARES-5320-x6425P



### ARES-5320-x6425A-ISO & ARES-5320-x6425P-ISO





## DC In Connector

**Connector Type:** Onboard 5.00 mm pitch 1x4-pin terminal block

**Pin Assignment:**

Pin	Description
1	Vin+
2	Vin-
3	PWR_SW-
4	PWR_SW+

Pin	Description
1	Vin+
2	Vin-
3	PWR_SW-
4	PWR_SW+



## Ignition Power Connector



**Function:** Ignition Power Connector

**Connector Type:** Onboard 2x1-pin box connector

**Pin Assignment:**

Pin	Description
1	ACC_ON+
2	GND

Pin	Description
1	ACC_ON+
2	GND






### COM Connectors


**Function:** COM1/2/ for RS-232/422/485, COM3/4 for RS-232 only

**Connector Type:** 9-pin D-sub Male Connector

Pin Assignment:	Pin	RS-232	RS-422	RS-485
	1	DCD	COM_422 TX-	COM_485 D-
	2	RXD	COM_422 TX+	COM_485 D+
	3	TXD	COM_422 RX+	
	4	DTR	COM_422 RX-	
	5	GND	GND	GND
	6	DSR		
	7	RTS		
	8	CTS		
	9	RI		



-x6425A/P




-x6425A/P-ISO

## 8-Bit DIO

**Function:** Digital IO Connector

**Pin Assignment:** Please refer to [Appendix A. DIO Signal Connections](#) on page [82](#)



## 2.3. LED Indicator Status

LED Indicator	Icon	Blinking Mode	Status
PWR Button		Solid Green	The system is in operation(S0)
		Solid Red	The system is in in sleep/hibernate mode(S3/S4) or power off mode(S5)
SATA HDD/SSD		Flashing Red	Data transmitting
RTC		Solid Green	RTC battery is low
PoE		Solid Green	Active

## 2.4. Driver Installation Note

For operating system of Windows 10, please go to our website at **[www.arbor-technology.com](http://www.arbor-technology.com)** and download the driver pack from the product page. Then unzip the downloaded file and follow the sequence below to install the drivers to prevent errors:

Chipset → Other drivers

Driver Path:

Driver	Path
Chipset	\\Chipset\setupchipset.exe
Audio	\\Audio\Setup.exe
Graphics	\\Graphics\gfx_win_101.2115\Installer.exe
Intel CSME	\\Intel CSME\SetupME.exe
Intel HID Event Filter	\\Intel HID Event Filter\HIDEventFilterDriver-2.2.1.384\Installer\Setup.exe
Intel Serial IO	\\Intel Serial IO\5.123.1.1023
LAN	\\LAN\Wired_driver_28.0_x64\Wired_driver_28.0_x64.exe


---

# Chapter 3

## Engine of the Computer

### 3.1. Board Overview

#### Main Board





### 3.1.1. Jumpers & Connectors

#### Jumpers

Label	Description
①JBAT1	Clear CMOS Selection
②JACCON1	Vehicle ACC mode selection
③JCOMV1/2	RI or Power Select Pin Header
④JCOMPWR1	RI Power Select Pin Header
⑤JDIOPWR1	DIO Power Select Pin Header

#### Connectors

Label	Description
①JSW1	Reset Pin Header
②JSW2	Power Button Pin Header
③BAT1	RTC Battery Connector
④MC2	Half-Size Mini PCI-e Socket
⑤MC3	Full-Size Mini PCI-e Socket
⑥MC1	Full-Size Mini PCI-e Socket
⑦SATAPWR1	SATA Power Connector
⑧SATA1	SATA 7-pin Connector
⑨AUDIO1	Audio Wafer Connector
⑩ETX1	Daughter Board Connector
⑪DGP1	Debug Port
⑫SIM1	Nano SIM Card Socket
⑬COM1/2	RS-232/RS-422/RS-485 Serial Port Header
⑭COM3/4	RS-232 Serial Port Header

### 3.1.2. Jumpers & Connectors Settings

#### ① JBAT1

**Function:** Clear CMOS Selection  
**Connector Type:** 2.0mm pitch, 1x2 pin header.  
**Pin Assignment:**

Pin	Description
<b>short</b>	Clear CMOS
<b>Open</b>	Keep CMOS(default)



#### ② JACCON1

**Function:** Vehicle ACC mode selection  
**Jumper Type:** 2.00 mm pitch 1x2-pin header  
**Setting:**

Pin	Description
1	DCIN
2	ACC_ON

1 2



Setting:  
 short: Automation mode(default)  
 open: Vehicle mode

#### ③ JCOMV1/2


**Function:** RI or Power Select Pin Header  
**Jumper Type:** Onboard 2.00mm-pitch 3-pin header  
**Setting:**

Pin	Description
1-2	RI(default)
2-3	RI_PWR



#### ④ JCOMPWR1

**Function:** RI Power Select Pin Header  
**Jumper Type:** 2.00 mm pitch 1x3-pin header  
**Setting:**

Pin	Description	
1-2	VCC5(default)	
2-3	VCC12	

#### ⑤ JDIOPWR1

**Function:** DIO Power Select Pin Header  
**Jumper Type:** Onboard 2.00mm-pitch 1x3-pin header  
**Setting:**

Pin	Description	
1-2	VCC5(default)	
2-3	VCC12	

#### ① JSW1

**Function:** Reset Pin Header  
**Connector Type:** 2.00 mm pitch 1x2 pin header  
**Pin Assignment:**

Pin	Description	
1	RESET#	
2	GND	

#### ② JSW2

**Function:** Power Button Pin Header  
**Connector Type:** 2.00 mm pitch 1x2 pin header  
**Pin Assignment:**

Pin	Description	
1	PWR_SW#	
2	GND	

③ **BAT1**

**Function:** RTC battery connector

**Connector Type:** Onboard 2x1-pin box connector

**Pin Assignment:**

Pin	Description
1	VBATT
2	GND




④ **MC2**

**Function:** Half-size mini PCI-e Socket (w/ PCIe 3.0 x1 + USB 2.0)

**Connector Type:** Mini PCI-e 52-pin Socket

**Pin Assignment:** The pin assignments conform to the industry standard




⑤ **MC3**

**Function:** Full-size mini PCI-e Socket (w/ PCIe 3.0 x1 + USB 2.0)


**Connector Type:** Mini PCI-e 52-pin Socket

**Pin Assignment:** The pin assignments conform to the industry standard



⑥ MC1

**Function:** Full-size mini PCI-e Socket (w/ SATA + USB 2.0)  
**Connector Type:** Mini PCI-e 52-pin Socket  
**Pin Assignment:** The pin assignments conform to the industry standard




⑦ SATAPWR1

**Function:** SATA Power Connector  
**Connector Type:** 2.54mm pitch 4-pin Wafer

**Pin Assignment:**

Pin	Description
1	VCC5
2	GND
3	GND
4	VCC12



⑧ SATA1

**Function:** Serial ATA Connector  
**Connector Type:** Standard 7-pin Serial ATA Connector

**Pin Assignment:**

Pin	Description	Pin	Description
1	GND	2	TXP
3	TXN	4	GND
5	RXN	6	RXP
7	GND		



⑨ **AUDIO1**

**Function:** Audio Connector  
**Connector Type:** 1.25 mm pitch 1x6 wire to board connector  
**Pin Assignment:**

Pin	Description
1	MIC_L
2	MIC_R
3	GND
4	GND
5	Line Out_L
6	Line Out_R



⑩ **ETX1**


**Function:** Daughter Board Connector  
**Connector Type:** 100-pin Connector  
**Pin Assignment:** ARBOR original design pin out  
**For requirement of customized daughter board, please contact ARBOR.**



⑪ **DGP1**

**Function:** Debug Port  
**Connector Type:** 2.00mm pitch 10-pin Header  
**Pin Assignment:**

Pin	Description	Pin	Description
1	ESPI_CLK	2	GND
3	ESPI_CS0#	4	ESPI_IO0
5	ESPI_RST#	6	3VSB
7	ESPI_IO3	8	ESPI_IO2
9	VCC3	10	ESPI_IO1




⑫ SIM1

**Function:** Nano SIM Card Socket

**Connector Type:** Nano SIM Card Socket

**Pin Assignment:** The pin assignments conform to the industry standard.



⑬ COM1/2

**Function:** RS-232/RS-422/RS-485 Serial Port Header

**Connector Type:** 2.00mm pitch 9-pin Header

Pin Assignment:	Pin	RS-232	RS-422	RS-485
	1	DCD	COM_422 TX-	COM_485 D-
	2	RXD	COM_422 TX+	COM_485 D+
	3	TXD	COM_422 RX+	
	4	DTR	COM_422 RX-	
	5	GND	GND	GND
	6	DSR		
	7	RTS		
	8	CTS		
	9	RI		



⑭ COM3/4

**Function:** RS-232 Pin Header

**Connector Type:** 2.00mm pitch 9-pin Header


Pin Assignment:		RS-232	
Pin	Description	Pin	Description
1	DCD	2	RXD
3	TXD	4	DTR
5	GND	6	DSR
7	RTS	8	CTS
9	RI		



### 3.2. Daughter Board - SCDB-148Q

Function: RS-232/422/485 Serial Port and isolated digital I/O daughter board  
Applicable models: ARES-5320-x6425A-ISO & ARES-5320-x6425P-ISO

#### Board Top:







### 3.2.1. Connectors Settings

#### ① COM5~COM8

**Function:** COM5/6/7/8 for RS-232/422/485

**Connector Type:** 9-pin D-sub Male Connector

Pin Assignment:	Pin	RS-232	RS-422	RS-485
	1	DCD	COM_422 TX-	COM_485 D-
	2	RXD	COM_422 TX+	COM_485 D+
	3	TXD	COM_422 RX+	
	4	DTR	COM_422 RX-	
	5	GND	GND	GND
	6	DSR		
	7	RTS		
	8	CTS		
	9	RI		




#### ② 16-Bit DIO

**Function:** Digital Input & Output

**Connector Type:** 20-pin Terminal Block

Pin Assignment:	Pin	Description	Pin	Description
	1	DIN_00	11	DOUT_00
	2	DIN_01	12	DOUT_01
	3	DIN_02	13	DOUT_02
	4	DIN_03	14	DOUT_03
	5	DIN_04	15	DOUT_04
	6	DIN_05	16	DOUT_05
	7	DIN_06	17	DOUT_06
	8	DIN_07	18	DOUT_07
	9	COM	19	GND_ISO
	10	+24V_ISO	20	GND_ISO



---

This page is intentionally left blank.

---

# Chapter 4

## Installation & Maintenance

## 4.1. Disassembling and Assembling the Computer


### 4.1.1. Disassembling the Computer

To use onboard jumpers/connectors or to install/remove internal components, you will need to open the computer to access the inside of the computer. Follow through the guide below to disassembly the computer. (Product photo varies according to the SKUs. But the disassembling procedures for various SKUs are basically the same.)

1. Remove the screws on the rear, bottom and top sides as shown below .



2. Then lift the L shape chassis away from the assembly.
3. Now you can access the components on the main board and configure or connect them as required.



## 4.1.2. Assembling the Computer

After you make required hardware installation and jumpers settings, assemble the computer by performing the proceeding steps in reverse order.


## 4.2. Installing the Hardware

### 4.2.1. Installing a Memory Module


1. Remove the top cover from the computer as described in [4.1. Disassembling and Assembling the Computer](#) on page [30](#).
2. Locate the SO-DIMM sockets on the main board.

The SO-DIMM sockets are vertical type, and each socket has two latches for fixing the memory modules. The memory module can only be installed by one direction due to the notch.


3. Pull back both latches from the socket.




4. Locate memory module sockets.



5. Confront the memory module's golden finger at the SO-DIMM socket. Position the memory module at the SO-DIMM socket, with the memory module's key notch aligned at the break of the SO-DIMM's slot connector.




6. Vertically plug the memory module to the DIMM socket. "Fully" plug the memory module until both latches auto-lock the memory module in place.




#### 4.2.2. Installing a SSD/HDD (for -x6425A and -x6425P)


1. Fasten two screws to secure the SATA and power connectors onto the bracket.




2. Slide the 2.5" HDD or SSD storage device into the drive bay and ensure it connects to the SATA connector. Using the 4 screws coming with the storage device kit, fix the storage device in place to the bracket.



3. Secure the drive bay back to the L-shape chassis by fastening the 4 screws you removed in Step 1.




4. Connect the SATA cable to the SATA connector on the adapter. Then connect the SATA power cable to the SATA power connector on the main board.



5. Reassemble the computer by performing the steps in [4.1.2. Assembling the Computer on page 31](#) in reverse order.


### 4.2.3. Installing a SIM Card and relative connection module

1. Remove the top cover from the computer as described in [4.1. Disassembling and Assembling the Computer on page 30](#).
2. Locate the SIM card slot on the main board.






- Slide the SIM card holder cover towards the OPEN edge and then lift the cover to open it.



- Insert the SIM card into the card holder as shown below.



- Close the SIM card holder door and slide the door to the LOCK edge to lock into place.



- Close the SIM card holder door and slide the door to the LOCK edge to


#### 4.2.4. Installing Wi-Fi Module

The computer has a mPCIe socket for Wi-Fi module installation. To install a Wi-Fi module:

- In order to make the half-size Wi-Fi module compatible with the Mini-card socket, extend the Wi-Fi module with a “mini half bracket”. Join them together by using two screws.





- Connect the RF antenna's MHF connector to the Wi-Fi module.



3. Plug the Wi-Fi module into the Mini-card socket by a slanted angle. Fully plug the module, and note the notch on the Wi-Fi module should meet the break on the connector. Press down the module and fix the module in place by fastening the screw.




4. From the SMA end of the RF antenna, remove the washer and the nut. Save the washer and nut for later use. Note that the SMA connector is in the form of a threaded bolt, with one flat side.



5. Remove the plastic plug from the antenna hole. Keep the plastic plug for any possible restoration in the future.



6. Pass the SMA connector through the above mentioned antenna hole. Make sure that you align the connector's flat side with the antenna hole's flat side.



7. Mount the washer first and then the nut to the SMA connector. Make sure the nut is tightened.



Mount the washer and the nut to the SMA connector. Tighten the nut.

8. If you are using two antennas, repeat the steps above for another antenna.
9. Have an external antenna. Screw and tightly fasten the antenna to the SMA connector. Swivel the antenna to an angle of best signals.


### 4.2.5. Installing GPS Module

The computer has a mPCIe socket for GPS module installation. To install a GPS module:



1. Locate the M.2 E-Key socket for GPS module.
2. Prepare the GPS module kit. The module is a Mini-card socket form factor.





3. Connect the antenna to the GPS module.



4. Plug the GPS module into the Mini-card socket by a slanted angle. Fully plug the module, and note the notch on the GPS module should meet the break on the connector. Press down the module and fix the module in place by fastening the screw.




5. From the SMA end of the RF antenna, remove the washer and the nut. Save the washer and nut for later use. Note that the SMA connector is in the form of a threaded bolt, with one flat side.



6. Remove the plastic plug from the antenna hole. Keep the plastic plug for any possible restoration in the future.



7. Pass the SMA connector through the above mentioned antenna hole. Make sure that you align the connector's flat side with the antenna hole's flat side.



8. Mount the washer first and then the nut to the SMA connector. Make sure the nut is tightened.



Mount the washer and the  
nut to the SMA connector.  
Tighten the nut.

9. If you are using two antennas, repeat the steps above for another antenna.
10. Have an external antenna. Screw and tightly fasten the antenna to the SMA connector. Swivel the antenna to an angle of best signals.


### 4.3. Ground the Computer

Follow the instructions below to ground the computer to land. Be sure to follow every grounding requirement in your place.



**Warning** Whenever the unit is installed, the ground connection must always be made first of all and disconnected lastly.

1. See the illustration below. Remove the ground screw from the bottom panel.
2. Attach a ground wire to the bottom panel with the screw.



-x6425A-ISO  
-x6425P-ISO



-x6425A  
-x6425P



---

## 4.4. Wire DC-in Power Source


### 4.4.1. Automation Mode



**Warning** Only trained and qualified personnel are allowed to install or replace this equipment.

Follow the instructions below for connecting the computer to a DC-input power source.

1. Before wiring, make sure the power source is disconnected.
2. Find the terminal block in the accessory box.
3. Use the wire-stripping tool to strip a short insulation segment from the output wires of the DC power source.
4. Identify the positive and negative feed positions for the terminal block connection. See the symbols printed on the rear panel indicating the polarities and DC-input power range in voltage.
5. Insert the exposed wires into the terminal block plugs. Only wires with insulation should extend from the terminal block plugs. Note that the polarities between the wires and the terminal block plugs must be positive to positive and negative to negative.
6. Use a slotted screwdriver to tighten the captive screws. Plug the terminal block firmly, which wired, into the receptacle on the rear panel.




---

#### 4.4.2. Vehicle Application Mode

Follow the instructions below for connecting the computer to a vehicle power source.

1. Make sure JACCON1 jumper is open for vehicle power mode. (Refer to [3.1.1. Jumpers & Connectors](#) on page 19.)
2. For vehicle application, DC power Input wiring pin configuration is as below. Please connect the Acc pin with your car Acc, and the device will be activated when you turn your ignition key to Acc.






---


## 4.5.2. DIN-Rail Mounting

To mount the computer using the provided DIN-rail mounting kit:

1. Select a proper mounting location with adequate wall strength to support the mounted unit.
2. Screw the DIN-rail mounting clip to the rear side of the computer.



Right View  
-X6425A/P-ISO




Back View  
-X6425A/P

---

After you screw the DIN-rail mounting clip to the computer:

1. Snap the DIN Rail clip to the upper edge of the DIN Rail.
2. Lift the computer firmly upward and then forward towards the DIN Rail until the DIN Rail clip tab engages and snaps to the upper edge of the DIN Rail.



---

This page is intentionally left blank.

---


# Chapter 5

## BIOS

## BIOS

The BIOS Setup utility is featured by American Megatrends Inc to configure the system settings stored in the system's BIOS ROM. The BIOS is activated once the computer powers on. When the computer is off, the battery on the main board supplies power to BIOS RAM.

To enter the BIOS Setup utility, keep hitting the “Delete” key upon powering on the computer.



Note: Actual model name and board information varies according to your model.

Menu	Description
Main	See <a href="#">5.1. Main</a> on page <a href="#">52</a>
Advanced	See <a href="#">5.2. Advanced</a> on page <a href="#">53</a>
Chipset	See <a href="#">5.3. Chipset</a> on page <a href="#">69</a>
Security	See <a href="#">5.4. Security</a> on page <a href="#">77</a>
Boot	See <a href="#">5.5. Boot</a> on page <a href="#">79</a>
Save & Exit	See <a href="#">5.6. Save &amp; Exit</a> on page <a href="#">80</a>



## Key Commands

The BIOS Setup utility relies on a keyboard to receive user's instructions. Hit the following keys to navigate within the utility and use the utility.


Keystroke	Function
← →	Moves left/right between the top menus.
↓ ↑	Moves up/down between highlight items.
<b>Enter</b>	Selects an highlighted item/field.
<b>Esc</b>	<ul style="list-style-type: none"> <li>▶ On the top menus: Use <b>Esc</b> to quit the utility without saving changes to CMOS. (The screen will prompt a message asking you to select <b>OK</b> or <b>Cancel</b> to exit discarding changes.</li> <li>▶ On the submenus: Use <b>Esc</b> to quit current screen and return to the top menu.</li> </ul>
<b>Page Up / +</b>	Increases current value to the next higher value or switches between available options.
<b>Page Down / -</b>	Decreases current value to the next lower value or switches between available options.
<b>F1</b>	Opens the <b>Help</b> of the BIOS Setup utility.
<b>F2</b>	Restore previous values.
<b>F9</b>	Loads optimized default values.
<b>F10</b>	Exits the utility saving the changes that have been made. (The screen then prompts a message asking you to select <b>OK</b> or <b>Cancel</b> to exit saving changes.)

Note: Pay attention to the "WARNING" that shows at the left pane onscreen when making any change to the BIOS settings.

This BIOS Setup utility is updated from time to time to improve system performance and hence the screenshots hereinafter may not fully comply with what you actually have onscreen.

## 5.1. Main


The **Main** menu features the settings of **System Date** and **System Time** and displays some BIOS info.



Note: Actual model name and board information varies according to your model.

Setting	Description
<b>System Date</b>	Sets system date.
<b>System Time</b>	Sets system time.

## 5.2. Advanced




Setting	Description
CPU Configuration	See <a href="#">5.2.1. CPU Configuration</a> on page <a href="#">54</a>
PCH-FW Configuration	See <a href="#">5.2.2. PCH-FW Configuration</a> on page <a href="#">55</a>
Trusted Computing	See <a href="#">5.2.3. Trusted Computing</a> on page <a href="#">56</a>
ACPI Settings	See <a href="#">5.2.4. ACPI Settings</a> on page <a href="#">58</a>
Super IO Configuration	See <a href="#">5.2.5. Super IO Configuration</a> on page <a href="#">59</a>
Hardware Monitor	See <a href="#">5.2.6. Hardware Monitor</a> on page <a href="#">61</a>
S5 RTC Wake Settings	See <a href="#">5.2.7. S5 RTC Wake Settings</a> on page <a href="#">62</a>
Serial Port Console Redirection	See <a href="#">5.2.8. Serial Port Console Redirection</a> on page <a href="#">63</a>
USB Configuration	See <a href="#">5.2.9. USB Configuration</a> on page <a href="#">64</a>
Network Stack Configuration	See <a href="#">5.2.10. Network Stack Configuration</a> on page <a href="#">66</a>
NVMe Configuration	See <a href="#">5.2.11. NVME Configuration</a> on page <a href="#">67</a>
SDIO Configuration	See <a href="#">5.2.12. SDIO Configuration</a> on page <a href="#">68</a>

### 5.2.1. CPU Configuration




Setting	Description
<b>Intel Virtualization Technology</b>	When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology ► Options: <b>Enabled</b> (default) or <b>Disabled</b>

## 5.2.2. PCH-FW Configuration



Setting	Description
<b>PTT Configuration</b>	Select TPM device: PTT or dPTM. PTT - Enables PTT in SKuMgr dTPM1.2 - Disables PTT in SKuMgr Warning! PTT/dTPM will be disabled and all data saved on it will be lost. ▶ Options: <b>Enabled</b> (default) or <b>Disabled</b>

### 5.2.3. Trusted Computing



Setting	Description
<b>Security Device Support</b>	This item enables or disables BIOS support for security device. OS will not show Security Device. Options are: <b>Enabled</b> (Default) / <b>Disabled</b>
<b>SHA256 PCR Bank</b>	Enables or disables SHA-1 PCR Bank. Options are: <b>Enabled</b> (Default) / <b>Disabled</b>
<b>Pending operation</b>	This item schedule an operation for the security device. Options are: <b>None</b> (Default) / <b>TPM Clear</b>
<b>Platform Hierarchy</b>	Enables or disables Platform Hierarchy Options are: <b>Enabled</b> (Default) / <b>Disabled</b>
<b>Storage Hierarchy</b>	Enables or disables Storage Hierarchy Options are: <b>Enabled</b> (Default) / <b>Disabled</b>
<b>Endorsement Hierarchy</b>	Enables or disables Endorsement Hierarchy. Options are: <b>Enabled</b> (Default) / <b>Disabled</b>

<b>Physical Presence Spec Version</b>	This item select to tell O.S. to support PPI Spec Version Options are: <b>1.3</b> (Default) / <b>1.2</b>
<b>Device Select</b>	TPM 1.2 will restrict support to TPM 1.2 devices, TPM 2.0 will restrict support to TPM 2.0 devices, Auto will support both TPM 2.0 devices and TPM 1.2 devices. Options are: <b>Auto</b> (Default)/ <b>TPM 1.2/TPM 2.0</b>


### 5.2.4. ACPI Settings



Setting	Description
<b>Enable Hibernation</b>	Only available when BIOS ACPI Auto Configuration is enabled. <b>Enables</b> (default) or <b>Disables</b> System ability to Hibernate (OS/S4 Sleep State). This option may be not effective with some OS.




## 5.2.5. Super IO Configuration



Note: The quantity of serial ports varies according to your model.

Setting	Description
<p><b>Serial Port 1/2/3/4/5/6/7/8 Configuration</b></p>	<p>To configure each COM port settings.</p> <p>Serial Port 1:</p> <ul style="list-style-type: none"> <li>▶ <b>Options: Enable and Disable Serial Port (COM) (default)</b></li> <li>▶ <b>Options: Mode Select for RS-232 (default) RS-422, RS-422(Termination Resistor), RS-485, RS-485(Termination Resistor)</b></li> </ul> <p>Serial Port2:</p> <ul style="list-style-type: none"> <li>▶ <b>Options: Enable and Disable Serial Port (COM) (default)</b></li> <li>▶ <b>Options: Mode Select for RS-232 (default) RS-422, RS-422(Termination Resistor), RS-485, RS-485(Termination Resistor)</b></li> </ul> <p>Serial Port3:</p> <ul style="list-style-type: none"> <li>▶ <b>Options: Enable and Disable Serial Port (COM) (default)</b></li> </ul> <p>Serial Port4:</p> <ul style="list-style-type: none"> <li>▶ <b>Options: Enable and Disable Serial Port (COM) (default)</b></li> </ul> <p>Serial Port5:</p> <ul style="list-style-type: none"> <li>▶ <b>Options: Enable and Disable Serial Port (COM) (default)</b></li> <li>▶ <b>Options: Mode Select for RS-232 (default) RS-422, RS-422(Termination Resistor), RS-485</b></li> </ul> <p>Serial Port6:</p> <ul style="list-style-type: none"> <li>▶ <b>Options: Enable and Disable Serial Port (COM) (default)</b></li> <li>▶ <b>Options: Mode Select for RS-232 (default) RS-422, RS-422(Termination Resistor), RS-485</b></li> </ul> <p>Serial Port7:</p> <ul style="list-style-type: none"> <li>▶ <b>Options: Enable and Disable Serial Port (COM) (default)</b></li> <li>▶ <b>Options: Mode Select for RS-232 (default) RS-422, RS-422(Termination Resistor), RS-485</b></li> </ul> <p>Serial Port8:</p> <ul style="list-style-type: none"> <li>▶ <b>Options: Enable and Disable Serial Port (COM) (default)</b></li> <li>▶ <b>Options: Mode Select for RS-232 (default) RS-422, RS-422(Termination Resistor), RS-485</b></li> </ul> <p>Note: The quantity of serial ports varies according to your model.</p>

## 5.2.6. Hardware Monitor




The page shows the PC health status.

### 5.2.7. S5 RTC Wake Settings




Setting	Description
<b>Wake System from S5</b>	<p><b>Enable or Disable</b> (default) system wake on alarm event.</p> <p>► Options available are:  <b>Disabled</b> (default):  <b>Fixed Time:</b> System will wake on the hr::min::sec specified.  <b>DynamicTime:</b> If selected, you need to set <b>Wake up minute increase</b> from 1 - 5. System will wake on the current time + increase minute(s).</p>

## 5.2.8. Serial Port Console Redirection



Setting	Description
<b>Console Redirection</b>	Use this item to enable or disable Console Redirection. The optional settings: <b>[Disabled]</b> ; <b>[Enabled]</b> . When set as <b>[Enabled]</b> , user can make further settings in the following items:
<b>Console Redirection EMS</b>	Console Redirection Enable or Disable The default setting is: <b>Disable</b> .


### 5.2.9. USB Configuration



Setting	Description
<b>Legacy USB Support</b>	<p>Enables/disables legacy USB support.</p> <ul style="list-style-type: none"> <li>▶ Options available are <b>Enabled</b> (default), <b>Disabled</b> and <b>Auto</b>.</li> <li>▶ Select <b>Auto</b> to disable legacy support if no USB device are connected.</li> <li>▶ Select <b>Disabled</b> to keep USB devices available only for EFI applications.</li> </ul>
<b>XHCI Hand-off</b>	<p>This is a workaround for Oses without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.</p> <ul style="list-style-type: none"> <li>▶ The optional settings are: <b>Enabled</b> (default) / <b>Disabled</b>.</li> </ul>
<b>USB Mass Storage Driver Support</b>	<p>Enables/disables USB Mass Storage Driver Support.</p> <ul style="list-style-type: none"> <li>▶ The optional settings are: <b>Enabled</b> (default) / <b>Disabled</b>.</li> </ul>
<b>USB hardware delay and time-out</b>	

<b>USB transfer time-out</b>	Use this item to set the time-out value for control, bulk, and interrupt transfers. ▶ Options: <b>1 sec, 5 sec, 10 sec, 20 sec</b> (default)
<b>Device reset time-out</b>	Use this item to set USB mass storage device start unit command time-out. ▶ Options available are: <b>10 sec, 20 sec</b> (default), <b>30 sec, 40 sec</b>
<b>Device power-up delay</b>	Use this item to set maximum time the device will take before it properly reports itself to the host controller. 'Auto' uses default value: for a root port it is 100 ms, for a hub port the delay is taken from hub descriptor. ▶ Options available are: <b>Auto:</b> Default <b>Manual:</b> Select <b>Manual</b> you can set value for the following sub-item: 'Device Power-up delay in seconds', the delay range in from 1 to 40 seconds, in one second increments.

### 5.2.10. Network Stack Configuration



Setting	Description
Network Stack	Enable or Disable (default) UEFI network stack.




## 5.2.11. NVMe Configuration



Access this submenu to view the NVMe controller and driver information.

## 5.2.12. SDIO Configuration




Setting	Description
<b>SDIO Access Mode</b>	Access SD device in DMA mode. Options are: <b>Auto, ADMA, SDMA, PIO</b>
<b>Mass storage device</b>	Mass storage device emulation type. Options are: <b>Auto, Floppy, Forced FDD, Hard Disk</b>

## 5.3. Chipset



Submenu	Description
<b>System Agent (SA) Configuration</b>	See <a href="#">5.3.1. System Agent (SA) Configuration on page 70</a>
<b>PCH-IO Configuration</b>	See <a href="#">5.3.2. PCH-IO Configuration on page 72</a>

### 5.3.1. System Agent (SA) Configuration



Submenu	Description
<b>System Agent (SA) Configuration</b>	
<b>Memory Configuration</b>	See <a href="#">5.3.1.1. Memory Configuration on page 71</a>
<b>Graphics Configuration</b>	See <a href="#">5.3.1.2. Graphics Configuration on page 72</a>
<b>VT-d</b>	<b>Enabled</b> (default) or <b>Disabled</b> VT-d function
<b>Above 4GB MMIO BIOS Assignment</b>	<b>Enabled</b> (default) or <b>Disabled</b> above 4GB MemoryMappedIO BIOS assignment.


### 5.3.1.1. Memory Configuration

Chipset		Aptio Setup - AMI	
Memory Configuration		Maximum Memory Frequency in Mhz. Must divide by 133 or 100 according to the refclk. In Gear2 must divide by 266 or 200. Lowest Gear2 speed is 2133	
Memory RC Version	0.0.4.111		
Memory Data Rate	2667 MT/PS		
Memory Timings (tCL-tRCD-tRP-tRAS)	19-19-19-43		
Channel 0 Slot 0	Populated & Enabled		
Size	16384 MB (DDR4)		
Number of Ranks	2		
Manufacturer	Samsung		
Channel 0 Slot 1	Not Populated / Disabled		
Channel 1 Slot 0	Not Populated / Disabled		
Channel 1 Slot 1	Not Populated / Disabled		
Maximum Memory Frequency	[Auto]	↑+: Select Screen ↓↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F9: Optimized Defaults F10: Save & Exit ESC: Exit	

Version 2.22.1282 Copyright (C) 2024 AMI

Access this submenu to view the memory configuration and adjust the memory Frequency.


### 5.3.1.2. Graphics Configuration



Note: This page varies according to your model.


Setting	Description
<b>Graphics Turbo IMON Current</b>	Graphics turbo IMON current values supported(14-31)
<b>Skip Scanning if External Gfx card</b>	Scanning for External Gfx Card on PEG and PCH PCIE Ports. Options are: <b>Disabled</b> (default), <b>Enabled</b>
<b>Aperture Size</b>	Select the Aperture Size ▶ Options: <b>128MB, 256MB</b> (default), <b>512MB,1024MB, 2024MB</b> .
<b>DVMT Pre-Allocated</b>	Select the DVMT 5.0 Pre-allocated (Fixed) Graphic Memory size used by the Internal Graphic Device. ▶ <b>60M</b> is the default.
<b>DVMT Total Gfx Mem</b>	Select the DVMT 5.0 Total Graphic Memory size used by the Internal Graphic Device. ▶ Options: <b>128MB, 256MB</b> (default) and <b>Max</b> .

### 5.3.2. PCH-IO Configuration



Setting	Description
<b>PCI Express Configuration</b>	See <a href="#">5.3.2.1. PCI Express Configuration on page 74</a>
<b>SATA Configuration</b>	See <a href="#">5.3.2.2. SATA Configuration on page 75</a>
<b>SCS Configuration</b>	Enable/Disable onboard NIC. ▶ Options are: <b>Enabled</b> (default), <b>Disabled</b> .
<b>Power on after power fail</b>	Specify what state to go to when power is re-applied after a power failure (G3 state) Options are: <b>Power on</b> , <b>Power Off</b>


### 5.3.2.1. PCI Express Configuration



Setting	Description
Intel Lan I226	<p><b>Intel Lan I226:</b> Control the PCI Express Root Port.</p> <ul style="list-style-type: none"> <li>▶ Options are: <b>Enabled</b> (default), <b>Disabled</b>.</li> </ul> <p><b>ASPM:</b> Set the ASPM level</p> <ul style="list-style-type: none"> <li>▶ Options are: <b>Disabled</b> (default), <b>L0s</b>, <b>L1</b>, <b>L0sL1</b>, <b>Auto</b></li> </ul> <p><b>L1 Substates:</b> PCI Express L1 Substates settings.</p> <ul style="list-style-type: none"> <li>▶ Options are: <b>Disabled</b> (default), <b>L1.1</b>, <b>L1.1 &amp; L1.2</b></li> </ul> <p><b>PCIe Speed:</b> Configure PCIe Speed.</p> <ul style="list-style-type: none"> <li>▶ Options are: <b>Auto</b> (default), <b>Gen1</b>, <b>Gen2</b>, <b>Gen3</b>, <b>Gen4</b></li> </ul>
Mini Card	<p><b>Mini Card:</b> Control the PCI Express Root Port.</p> <ul style="list-style-type: none"> <li>▶ Options are: <b>Enabled</b> (default), <b>Disabled</b>.</li> </ul> <p><b>ASPM:</b> Set the ASPM level</p> <ul style="list-style-type: none"> <li>▶ Options are: <b>Disabled</b> (default), <b>L0s</b>, <b>L1</b>, <b>L0sL1</b>, <b>Auto</b></li> </ul> <p><b>L1 Substates:</b> PCI Express L1 Substates settings.</p> <ul style="list-style-type: none"> <li>▶ Options are: <b>Disabled</b> (default), <b>L1.1</b>, <b>L1.1 &amp; L1.2</b></li> </ul>




### 5.3.2.2. SATA Configuration




Setting	Description
<b>SATA Controller(s)</b>	<b>Enabled</b> (default) / <b>Disabled</b> SATA device(s).
<b>Aggressive LPM Support</b>	<b>Enabled</b> / <b>Disabled</b> (default).
<b>Serial ATA Port 0/1</b>	SATA device information. *Available SATA ports depend on your device.
<b>Port 0/1</b>	<b>Enables</b> (default) / <b>disables</b> the SATA port.
<b>SATA Port 0/1 DevSlp</b>	<b>Enables</b> / <b>disables</b> (default) the SATA port DevSlp. Board rework for LP needed before enable.

### 5.3.2.3. SCS Configuration




Setting	Description
<b>eMMC 5.1 Controller</b>	<b>Enabled</b> (default) / <b>Disabled</b> SCS eMMC 5.1 Controller.
<b>eMMC 5.1 HS400 Mode</b>	<b>Enabled</b> (default) / <b>Disabled</b> SCS eMMC 5.1 HS400 Mode.
<b>Enable HS4000 software tuning</b>	<b>Enabled</b> (default) / <b>Disabled</b> software tuning at expense at boot of time.
<b>Driver Strength</b>	Sets I/O driver strength. Options are: <b>33 Ohm, 40 Ohm, 50 Ohm</b>
<b>SDcard 3.0 Controller</b>	<b>Enabled</b> (default) / <b>Disabled</b> SCS SDHC 3.0 Controller

## 5.4. Security



Setting	Description
<b>Administrator Password</b>	To set up an administrator password: <ol style="list-style-type: none"> <li>1. Select <b>Administrator Password</b>.</li> <li>2. An <b>Create New Password</b> dialog then pops up onscreen.</li> <li>3. Enter your desired password that is no less than 3 characters and no more than 20 characters.</li> <li>4. Hit [Enter] key to submit.</li> </ol>
<b>Security Boot</b>	See <a href="#">5.4.1 Security Boot on page 78</a>

### 5.4.1. Security Boot




Setting	Description
<b>Secure Boot</b>	<b>Enabled/Disabled</b> (default) secure boot.
<b>Secure Boot Mode</b>	Allow users to set the secure boot selector. Options are: <b>Standard/Custome</b> (default) mode.
<b>Restore Factory Keys</b>	Force system to restore default secure boot key database.
<b>Reset to Setup Mode</b>	Delete all secure boot key databases.
<b>Key Management</b>	Allow users to modify secure variables and set key management page.

## 5.5. Boot



Setting	Description
<b>Setup Prompt Timeout</b>	Set how long to wait for the prompt to show for entering BIOS Setup. <ul style="list-style-type: none"> <li>▶ The default setting is <b>1</b> (sec).</li> <li>▶ Set it to <b>65535</b> to wait indefinitely.</li> </ul>
<b>Bootup NumLock State</b>	Sets whether to enable or disable the keyboard's NumLock state when the system starts up. <ul style="list-style-type: none"> <li>▶ Options available are <b>On</b> (default) and <b>Off</b>.</li> </ul>
<b>Quiet Boot</b>	Sets whether to display the POST (Power-on Self Tests) messages or the system manufacturer's full screen logo during booting. <ul style="list-style-type: none"> <li>▶ Select <b>Disabled</b> to display the normal POST message, which is the default.</li> </ul>
<b>Boot Option Priority</b>	Set the system boot priorities.
<b>Power Delay Function</b>	Set the system support power delay function <ul style="list-style-type: none"> <li>▶ Options are: Enabled -&gt; Support power delay function.</li> <li>Disabled -&gt; Power on/off manually operated.</li> </ul>

## 5.6. Save & Exit



Setting	Description
<b>Save Changes and Exit</b>	Saves the changes and quits the BIOS Setup utility.
<b>Discard changes and Exit</b>	Exit system setup without saving the changes.
<b>Restore Defaults</b>	Restore/Load defaults values for all the setup options.
<b>Boot Override</b>	<b>Boot Override</b> presents a list in context with the boot devices in the system.

---

# Appendix


---

## Appendix A. DIO Signal Connections

### A.1. 8-Bit DIO Signal Connections (for -x6425A and -x6425P)

The 4 x DI, 4 x DO connector offers 8-bit DIO, power (+5V) and ground pin. Each bit of DIO can be set as digital input or output.

Please see the DC characteristics for detail.



Parameter	SYM.	MIN.	TYP.	MAX.	UNIT	Conditions
I/OD TTL Level bi-directional pin with schmitt trigger, open drain output with 12mA source-sink capability, 5V tolerance						
Input Low Threshold Voltage	VI-			0.8	V	
Input High Threshold Voltage	VI+	2.0			V	
Output Low Current	IOL		+12		mA	VOL=0.4V




## A.2. 16-Bit Opto-Isolated DIO Signal Connections (for -ISO)


### A.2.1. Wet Contact DI with NPN / PNP connection

Digital Input - Wet Contact	
$V_{off}$	$V_{on}$
Max. 6V	12~24V

PNP




NPN




### A.2.2. Dry Contact DI with NPN / PNP connection

PNP



NPN



### A.2.3. Isolated Digital Output Connections

When an isolated output channel is being used as an output channel, if an external voltage (maximum 24V) is applied, the current will flow from the external voltage source to the system. Make sure that the current through each out pin does not exceed 100 mA.

